Plan your wall.

Use this guide to plan quantities, prepare your wall and discuss installation details. Final installation must follow the current supplier instructions and the adhesive manufacturer’s requirements.

THE FORMAT

Panel dimensions	600 × 2600 × 4 mm
Coverage per panel	1.56 m² / approximately 16.79 sq. ft.
Inside each box	2 panels / 3.12 m² / approximately 33.58 sq. ft.
Carton dimensions (L × W × H)	2615 × 613 × 16 mm

QUANTITY EXAMPLE

100 sq. ft. + 10% allowance = 110 sq. ft. to plan for

4 boxes / 8 panels

Nominal coverage supplied: 134.33 sq. ft. (12.48 m²).

The 10% allowance is an example, not a fixed installation requirement. Wall dimensions, openings, cuts and full-panel layout can change the quantity needed.

MEASURE AND DRY-FIT

Measure the width and height of each wall. Mark doors, windows, outlets, corners and finishing details. Sketch the panel positions and dry-fit the layout before cutting or applying adhesive.

PREPARE THE SURFACE

Plan for a clean, dry, flat and stable wall surface. Confirm the substrate and any preparation needed with the supplier or your installer before fitting the panels.

Confirm the details.

Use the checks below with your supplier or installer. This is planning guidance, not a replacement for the final product-specific installation instructions.

01 Adhesive and substrate

Use a suitable neutral mounting adhesive compatible with the panel and wall substrate. Follow the current supplier and adhesive instructions for application, handling and curing conditions.

02 Dry-fit and cutting

Check the layout and pattern orientation before cutting. Confirm the cutting tool and method with the supplier for your panels. Plan cuts around openings and allow for the chosen edge trims.

03 Joints and finishing

Follow the supplier’s tongue-and-groove installation method and end-trim details. Confirm the joint, corner and edge-finishing requirements before fixing the panels in place.

BATHROOMS AND SHOWERS

Before use in a bathroom or shower, confirm the complete waterproofing system, substrate, adhesive and joint/edge-sealing requirements with the supplier and installer. Decorative panels alone do not form a complete waterproof wall assembly.

ROUTINE CARE

Wipe with a damp cloth or mild cleaner, following the supplier’s current care guidance for the finish.

CHECK THE FINISH BEFORE ORDERING

Review a physical sample in your own space and lighting before making a final finish choice. Contact Cavador to discuss the finish, quantity and materials required for your project.

www.cavador.ca/pages/contact

Nominal coverage is calculated from the confirmed panel dimensions. Actual layout and cuts affect usable coverage.